


ET400 Start Guide Rev00

1. Power On

- Connect the screen to the machine.
- Connect the pedal to the machine.
- Connect the Ethernet cable to the machine.
- Make sure the E-stop button is released.
- Turn on the power switch.



2. Feeding

Step 1: Adjust the limit block (see ET400 manual), and feed the material through the guide rod into the inlet.

Step 2: Hold the feeding button and pull the film to the drive area until it reaches the outlet port, indicating success.





3. Operation



Note: After entering each mode, verify that the material type matches the selection on the touchscreen to avoid errors.

Mode	Operation
حسرد	Press pedal or Jog to start, hold to extend the connected pads, and release to move to the next tear line
	a. Release immediately to tear one piece.
Manual	b. Hold to tear the maximum number of connected pieces.
\rightarrow	The mode allows presetting the number of connected pads for separation and controlling the discharge method.
Œ	: Trigger once to separate the preset number of pads.
Once	Trigger once for continuous separation of the preset pads, with automatic production of the next section after removal.
<u>د</u>	This mode allows presetting the number of connected pads and target sections. The machine stops after reaching the target.
Batch	It can be paused midway. 💼 : Clear the produced quantity.
Preset	This mode allows presetting multiple pad counts. Tap the value on the screen, and the machine separates the film accordingly.
Recipe	This mode allows setting a series of production formulas with various pad counts and target sections.
	It has single/multi-cycle modes with discharge similar to
	Stops after completing the entire formula.
	Cycles discharge until stopped by the operator or material runs out.
	: Clears produced quantity, restarting from the first group when triggered again.